

Rockwell 90 degree Europrofile Keylock Cylinder

INSTALLATION INSTRUCTIONS

1. Push the tab (A) switch downward to unlock the drive tab (C).
2. Rotate knob (B) until the drive tab (C) is at 6 o'clock and aligned with the cylinder (D).
3. Holding the drive tab (C) in this position, insert the cylinder body into the interior backplate so the key plug from the cylinder protrudes through the exterior side of the door.
4. Once the cylinder body is in the correct position, rotate the knob (B) to disengage the tab (A). Test the installation by rotating the knob (B) or using the key to extend and retract the deadbolt.
5. Fix cylinder body in place in the lockset with the europrofile cylinder screw.

TO REMOVE CYLINDER:
Loosen and remove the cylinder screw and repeat steps 1-4 above.

