

# Rockwell 360 degree Europrofile Keylock Cylinder

## INSTALLATION INSTRUCTIONS

1. Rotate knob (B) until the drive tab (C) is at 6 o'clock and aligned with the cylinder (D).
2. Holding the drive tab (C) in this position, insert the cylinder body into the interior backplate so the key plug from the cylinder protrudes through the exterior side of the door.
3. Once the cylinder body is in the correct position, rotate the knob (B) Test the installation by rotating the knob (B) or using the key to extend and retract the deadbolt.
4. Fix cylinder body in place in the lockset with the europrofile cylinder screw.

